

Replacing Weather Cover Fasteners

List of parts:

(with CTS part numbers)
Receptacles- ¼ turn (R-011-063)
Slotted studs- 1/4 turn (R-011-064)

List of tools:

Flat head screwdriver
Pliers (bull-nose, or others with a flat nose)

Removal Instructions

1. Make certain the scoreboard is disconnected from AC power and turned off.
2. Remove the first weather cover by turning the slotted studs a quarter turn using a flathead screwdriver so that they are vertical. Remove the weather cover and set it in a place where you can work with it.
3. Working from the inside of the weather cover, pinch the receptacle with the bull-nose pliers as shown. It will work best if you align the pliers so they are squeezing along the short direction of the weather cover. Wiggle the receptacle out of the weather cover. The slotted stud will come out with it. If you are viewing this pdf online, click on the picture at right to see a video of this process; if not, you can view this document in the online manuals section of our website.
4. Continue for all receptacle/slotted stud pairs on this weather cover. Recycle or scrap the used receptacles and slotted studs.



Installation Instructions

1. Gather enough new receptacles for the weather cover you are working with.
2. Replace the weather cover on enclosure with matte side out.
3. Push new weather cover fastening receptacles (R-011-063) in firmly with marks horizontal, as shown.
4. Insert slotted studs (R-011-064) and turn ¼ turn to tighten. They will snap into place when properly secured.
5. Continue until all weather covers have new receptacles and slotted studs.

