




Drilling Instructions: Preparing OSB12 Track Start Blocks For RJPLD-OSB12 Relay Judging Platforms

1. Hook RJPLD-OSB12 over front edge of starting block and slide into place. Make sure it is on as firmly as possible, and that the front lip is tight against the block. Center the RJPLD from side to side on the block. Mark the mounting hole locations onto the OSB12 in the center of the 2.5 x 1.4 cm oblong holes in the back end of the RJPLD.



2. Remove the RJPLD-OSB12 relay judging platform. Re-mount it, and determine if you can align it with the marks. If not, re-mark the mounting hole locations in a different color.
3. Once you have successfully mounted the RJPLD-OSB12 in the same location twice, remove the RJPLD and drill 7mm holes at the final marks.