

Championship Elite Starter Firmware Updates

F1072 202502

Note:


Starter must be fully charged before starting update

Tools Required:


- Computer with USB (A to B or C to B) cable
- CTS Starter Programmer Software:
 - Download from <https://coloradotime.com/support/software-downloads#other>
- #2 Philips head Screwdriver

Steps:


1. Open the starter
 - a. Remove 6 screws (3 on each side).




- b. lift case top up, then rock back (towards display)



2. Plug in USB cable




3. Turn on starter. (Note: LED will flash yellow due to no microphone being connected.)




4. Navigate to downloaded StarterProgrammer_x.x.x.zip file and double click the StarterProgrammer_x.x.x.exe file to run the program (Ex: StarterProgrammer_1.0.6.exe)


5. Click “Scan for Starter”



6. Click “Load Starter Firmware”



7. Click “Update Starter”



8. Wait for update process to complete
 - a. Starter will power down after update
9. Remove USB cable
10. Close starter back up
 - a. Elite: hinge lid forward, then press down (be sure to check for any stray cables). Re-attach 6 screws